



3-WAY SWITCHES

SWITCH ONE
BATTERY CONNECTION ⇒



⇐ OR SWITCH BOTH
BATTERY CONNECTIONS